


Maintenance Manual

EA-400

Doc.- No. EA-05702



EXTRA
FLUGZEUGBAU GMBH

Schwarze Heide 21 • D - 46569 Hünxe • Germany

Tel.: + 49 28 58 / 91 37 - 0 • Fax: + 49 28 58 / 91 37 - 30

CONTENTS

Title.....	Page
List of Effective Pages	A-F
Record of Revisions	G
List of Service Bulletins	H

Group / Chapter Title	Chapter
-----------------------------	---------

GENERAL

Introduction	01
How to Use the Service Manual	02

AIRCRAFT

General Description	03
Airworthiness Limitations	04
Time Limits/Maintenance Checks	05
Dimensions and Areas	06
Lifting and Shoring	07
Leveling and Weighing	08
Towing and Taxiing	09
Parking, Mooring, Storage and Return to Service	10
Placards and Markings	11
Servicing	12
Standard Practices - Airframe	20

AIRFRAME SYSTEMS

Air Conditioning.....	21
Communications.....	23
Electrical Power	24
Equipment/Furnishings	25
Flight Controls	27
Fuel	28

Group / Chapter Title	Chapter
Hydraulic Power	29
Ice and Rain Protection	30
Indication/Recording Systems	31
Landing Gear	32
Lights	33
Navigation	34
Vacuum	37

STRUCTURES

Standard Practices and Structures - General	51
Doors	52
Windows	56
Wings	57

PROPELLER

Propeller	61
-----------------	----

POWER PLANT

Power Plant	71
Engine	72
Engine Fuel and Control	73
Ignition	74
Engine Controls	76
Engine Indicating	77
Exhaust	78
Oil	79
Starting	80
Turbines	81